



Accessori barbecue
Barbecue accessories




CB 5042/AM
Coperchio
Cover




B/T
Tagliere in legno
Wooden chopping-board




B/C
Coperchio tegame
Pan lid




B/MR
Motoriduttore universale per spiedi
Universal geared moto for spits




B/TP
Tagliere in legno porta piastre e tegami
Chopping-board for carrying tray and pans




B/TB
Tegame basso
Low-edged pan




B/S
Spiedo con bloccaggio tridente
Spit with adjustable tridental food holders




B/PCl
Piastra cottura liscia
Flat cooking tray




B/TM
Tegame medio
Medium-edged pan




B/S3
Tre spiedini per piccola cottura
Three small spits for small foods




B/PCR
Piastra cottura rigata
Ridged cooking tray



B/TA
Tegame alto
High-edged pan



SB/PCV
Staffe pentola cottura a vapore per barbecue
Barbecue steamer brackets



PCV
Pentola cottura a vapore
Steamer